



XM ROTATION AXIS CALIBRATION CHECK

1. INTRODUCTION

This procedure is used to check the calibration the XM System Rotation Axis Motion function to assure accurate and reliable positioning of the motion control devices. This procedure applies to all XM Modules loaded with Rotation Axis firmware.

2. RESPONSIBILITIES

Performer	Responsibility
Technician	After assuring prerequisites are met, performs a calibration check of the Rotation Axis Module functions using steps 4.1 through 4.8 of this procedure. If calibration check fails, initiate troubleshooting using step 4.9 and the NOTE at the end of this procedure as guidance.

3. PREREQUISITS

Record the XM Module serial number in Section 5, *RECORDS*. The following tools and equipment are needed to perform this calibration:

- 3.1 A non-permanent pen or pencil.

4. INSTRUCTIONS

- 4.1 Press the SETUP Mode Button on the controller.
- 4.2 Use the SELECT MODULE Programming Knob to highlight the Rotary Axis.
- 4.3 Press the CALIBRATE Programming Knob to enter the CALIBRATION Mode.
- 4.4 Set a desired velocity using the ADJUST VELOCITY Programming Knob.
- 4.5 Set the length of rotational travel to 360 degrees using the ADJUST LENGTH Programming Knob. (An alternate rotational angle may be set. However, 360 degrees provides the easiest measurement.)
- 4.6 Mark the position of the rotary axis using a non-permanent pen or pencil. This mark will be used to determine the actual degrees of travel.
- 4.7 Press the **Start** Sequence Button on the controller.
- 4.8 When rotation has stopped, verify the axis has rotated exactly 360 degrees (or the value set in step 4.5). If the rotation is accurate, no adjustment is needed and the calibration check is complete. If the rotation was other than 360 degrees (or the value set in step 4.5) continue with step 4.9. If you have already completed step 4.9 and the rotation is still incorrect, refer to the NOTE below.
- 4.9 Press the CLOSE Soft Button. Verify that the Rotary Axis Module being checked is still highlighted. Press the CONFIGURE Programming Knob to enter the CONFIGURATION Mode. Press the CUSTOMIZE Soft Button. Press the LOAD Soft Button. Use the SELECT Programming Knob to highlight the configuration file for the rotary device being checked. Press the LOAD Soft



Doc. No.: TP-XM-003

Revision: 1

Page: 2 of 2

Effective Date: 10/02/2007

XM ROTATION AXIS CALIBRATION CHECK

Button. Once this is complete, press the CLOSE Soft Button twice to exit the Configuration Mode. Repeat Steps 4.1 through 4.8.

NOTE: When in Rotation Configuration Mode as described in step 4.9, you will notice a “Counts/Unit” parameter on the right hand side of the display when “Rotator” is selected on the left hand side of the display. The existing value of the “Counts/Unit” parameter is based on the encoder counts and the drive ratio of the rotator motor and gear box assembly. If the rotational axis does not rotate accurately to a set distance, then either the “Counts/Unit” parameter has changed from its original value or there is a mechanical discrepancy with the rotator assembly. In order to determine the source of the problem, continue with the following steps:

1. Verify that all mechanical connections are sound and there is no slippage of the motor shaft to the encoder or gear box.
2. If there are no mechanical discrepancies, contact AMET Inc., Technical Support for the correct “Counts/Unit” value.

5. RECORDS

Technician:

Date:

XM Module Serial Number:

6. DEFINITIONS

None

7. REFERENCES

- 7.1 XM System Manual, SM-001
- 7.2 XM Maintenance Manual, MM-001 (DRAFT)

8. APPENDIXES

None